

Product: 2029 Boot Saver Film provides a quick, cost-efficient method for controlling dirt seed contamination and paint-tracking in the paint booth. This adhesive film covers work boots upon entering the cleanroom areas, thereby encapsulating any dirt seeds and preventing their migration into the paint shop. It can also be used to temporarily protect the workers boots when exiting the booth, to eliminate paint tracking. Perforations eliminate the need for knives or scissors. These covers are fiber-free and paintshop safe.



Paint Overspray and Paint Tracking Damage



2029 Application

Benefits:

- Fiber-free.
- Secure fit, will not fall off.
- Disposable, one size fits all simplicity.
- Perforated for easy tearing.
- Protects boots, and reduces paint tracking.
- Prevents dirt contamination from entering paint area.

Usage: Load applicator with 2029 film. Place at cleanroom and paint booth entry areas. Unroll a layer of film and place flat on incline surface. Place boot on to center of panel and tear at perforation ahead of the boot's toe. The adhesive edge can be lifted and re-applied to improve fit. Apply additional layer if leaving paint booth temporarily. Or remove completely and reverse wrap into a ball before disposing.

Size: 0.20m x 100m (200+ wraps/roll)